

P7906 VIBRASONIC MOLECHASER[®]

KEEP BURROWING RODENTS OUT OF YOUR GARDEN FOREVER!

The new **VIBRASONIC MOLECHASER[®]** features; solid construction, user-friendly easy battery installation/replacement, is maintenance free and 100% weather proof. Utilizing the principle of centrifugal force to create sound and vibration by motor, your **VIBRASONIC MOLECHASER[®]** is the most effective, humane and environmentally friendly way of keeping gardens and lawns free of destructive ground rodents.

The **VIBRASONIC MOLECHASER[®]** consists of a solid aluminum shaft, a battery box, and a uniquely designed sophisticated driving system. The unit also features a water-tight cap. After installing the batteries, you will be able to see, touch, hear, the strong effect of the **VIBRASONIC MOLECHASER[®]**.

Most underground rodents have poor eyesight, yet nature has given them a very acute sense of hearing and sensitivity to ground vibration. The **VIBRASONIC MOLECHASER[®]** exploits this sensitivity to produce a penetrating vibration over an area of approx. 13,500 sq. ft. (1/3 Acre) at 18 second intervals.

- **VIBRASONIC MOLECHASER[®]** is completely harmless to worms and other underground bugs.
- **VIBRASONIC MOLECHASER[®]** operates in a circular pattern, approx. 130 ft. in diameter. This must be an unobstructed 130 ft.
- Place **VIBRASONIC MOLECHASER[®]** at site of worst rodent infestation.
- Remove **VIBRASONIC MOLECHASER[®]** if ground freezes or when flooding occurs.
- Replace battery after approximately 4-6 months or when sound is no longer audible.

BURROWING RODENTS AFFECTED:

Moles * Ground Squirrels * Also, Shrews, Voles, Pocket Mice and Gophers

OPERATING INSTRUCTIONS:

1. To open, unscrew top cover counter-clockwise.
2. Remove Battery Box and insert 4 X D cell batteries as indicated. If battery installation is correct, you should hear the first vibrating sound within 18 seconds.
3. After ensuring battery installation is correct, replace Battery Box and tighten Top Cover to ensure 100% maximum weather protection.
4. Insert **VIBRASONIC MOLECHASER[®]** into the ground fully or up to the Corrugated Portion. Your **VIBRASONIC MOLECHASER[®]** will work Day and Night.
5. If you prefer, you may insert the unit all the way into the ground. This will prevent the chance of running over the unit with your lawnmower. If you choose this option be certain to insert the unit so that the top of the top cover is flush with the surface. If you leave it protruding an inch or two it could be a tripping hazard. Be sure to note the location of the unit so that you can find it to replace batteries or remove it for the season.

The Unit will work for 4-6 months on one set of alkaline batteries. To replace batteries simply repeat steps 1-3.

Please note damaged lawns, shrubs, etc will take up to 6 weeks to rejuvenate.

Climate permitting, leave your **VIBRASONIC MOLECHASER[®]** in ground to repel new generations of pests.

SPECIFICATION:

Dimensions : 16"(L) X 2"(dia.)

Weight : 14oz. w/o Battery

Power Supply : 1.5V (4XD cell Batteries)

Effective Range : 13,500 sq. ft. (1/3 Acre) unobstructed

IMPORTANT:

Top cover of **VIBRASONIC MOLECHASER[®]** must be tightened again after insertion into the ground so there can be no possibility of water damage.

Make a pilot hole before inserting **VIBRASONIC MOLECHASER[®]** into hard ground. *DO NOT HAMMER OR PUSH EXCESSIVELY OR YOU MAY DAMAGE UNIT.

Range of effectiveness depends largely upon soil type: Dry, sandy, or peat soil does not conduct the vibrant sonic wave easily and sometimes two **VIBRASONIC MOLECHASER**® may be required. Moist clay is the best conductor of sound. Do not expect instant reaction - **VIBRASONIC MOLECHASER**® must be used continuously for up to 7-14 days before ground rodents start to move away from the area.